

PARTS FOR MODELS:		JST75 6"			
NO.	Description	Code Number	Materials	Notes,Standards	Q' TY
JST75(01)	Strainer	010013	ST		1
JST75(02)	Suction cover	020011	FCD 400		1
JST75(03)	Nut	305503	SUS 304	M20	1
JST75(04)	Washer	305504	SUS 304	M20	1
JST75(05)	Impeller	050052	FCD 400	50HZ	1
JST75(05)	Impeller	050055	FCD 400	60HZ	1
JST75(06)	Key	060003	SUS 304	5*5*20	1
JST75(07)	Pump housing	070012	FC 200		1
JST75(08)	Cover of oil chamber	080007	FC 200		1
JST75(09)	Lip seal	090004	NBR	TC 35*62*10	1
JST75(09-2)	Lip seal	092001	NBR	DC35*62*12	1
JST75(10)	Shaft sleeve	100007	SUS 304	φ 25* φ 35*42L	1
JST55(11)	Plugs(08)&(26)	104011	SUS 304	M6*8	2
JST75(12)	Lip seal	30551201	NBR	TC 32*58*8	1
JST75(13)	Mechanical seal	305513/30551301	CAR/SIC	φ 32	2
JST75(14)	Bearing (bottom)	307514		6307LLB	2
JST75(14-2)	Bearing cover	305514-2	SUS 304		1
JST75(16)	Motor casing	307516	SUS 304	3t* φ 190*300	1
JST75(17)	Rotor shaft	170022	SUS 304	108*160	1
JST75(18)	Stator	307518		φ 190*108*160	1
JST75(20)	Bearing (up)	302214		6305LLB	1
JST75(21A)	Motor bottom cover	307521A	FC 200		1
JST75(23)	Overload protector	307523		KA314-HLXLOO	1
JST75(26)	Upper cover	305526	FC 200		1
JST75(27)	Cable gland	30222701	FC 200		1
JST75(28)	Rubber sleeve	280001	NBR		1
JST75(31)	Cable	305531		H07RNF 6*4*10M	1
JST75(31D)	Sensor	311002	CU	45mm (DV)	1
JST75(32)	Cable Clamps	320004	SUS 316+NBR		1
JST75(34)	Handle	305534	SUS 304		1
JST75(38E)	Elbow	384004	FC 200		1
JST75(38F)	Flange	381006	FC 200	6"	1
JST75(08-1)	Oring	305516-1	NBR	φ 178*2.6	1
JST75(10-1)	Oring	101001	NBR	φ 23.5*2	1
JST75(10-01)	Oring	102001	NBR	φ 28*4	1
JST75(16-1)	Oring	305516-1	NBR	φ 178*2.6	1
JST75(20-1)	Oring	305520-1	NBR	φ 62*2.6	1
JST75(26-1)	Oring	305516-1	NBR	φ 178*2.6	1
JST75(27-1)	Oring	271001	NBR	φ 45*3	1
JST75(38E-1)	Gasket	382003	NBR		1
JST75(38F-1)	Gasket	386003	NBR		1
JST75(50-01)	Screw	305550-38E	SUS 304	M8*90	3
JST75(50-02)	Screw	107550-21A	SUS 304	M8*30	4
JST75(50-08)	Screw	104050-34	SUS 304	M6*12	6
JST75(50-14-2)	Screw	104050-34	SUS 304	M6*12	2
JST75(50-23)	Screw	107550-23	SUS 304	M4*12	2
JST75(50-26)	Screw	307550-26	SUS 304	M8*340	6
JST75(50-27)	Screw	302250-05W-3	SUS 304	M6*20	3
JST75(50-31E)	Screw	101050-31E	ST	M4*6	1
JST75(50-32)	Screw	500017/500037	SUS 304	M5*15/N5	1/1
JST75(50-34)	Screw	500027/302250-02	SUS 304	M8*15/M8*20	2/1
JST75(50-38E)	Screw	500030/500042	SUS 304	M12*65/N12	4/4
JST75(50-38F)	Screw	500046/500043	SUS 304	M16*70/N16	8/8